

## DATA SHEET



### **STEP<sup>®</sup> YLS** Special Torque-resistant Edging Pad Yellow Lens Side

Explanation:	Super Hydrophobic Coating weakens surface tension to facilitate run-off of water droplets from the lens surface. It reduces visual distortion arising when wearing glasses or sunglasses around water or in the rain. It also resists stains and repels grease and fingerprints, so cleaning your lenses is quicker and easier. This kind of lenses are specified as Super Hydrophobic or Oleophobic lenses and it is almost impossible to attach a blocking pad to it.
Product Description:	This PE foam pad features a unique internal reinforcement to prevent stretching and thus reduce axis problems. Moreover it is provided with the latest hybrid adhesive technology. One side has a special engineered adhesive that attaches to the latest generation of Super Hydrophobic coatings and the other side has an adhesive specially for the block side. Both adhesives are clean removable.
Directions for use:	Lens side is indicated by a yellow pull tab. Block side is indicated by a red pull tab. <b>Note: This pad is only suitable for Super Hydrophobic or Oleophobic lenses</b>
Physical Properties:	
Adhesive:	Hybrid adhesive technology
Carrier:	Conformable reinforced closed cell PE foam 0,9mm
Total Thickness:	1,0 mm
Liner:	Manual roll: White Glassine Paper and PET Machine roll: PE and PET
Temperature :	+90°C
Shelf Life:	12 months from despatch when stored in original bags and cartons at 21°C and under 50% relative humidity

*Data and details in this sheet were correct and up-to-date at the time of printing and are intended to provide information on our products and their possible applications. This sheet is not a specification and does not assure specific product characteristics or make reference to the suitability of the products for a definite application. Because Permanento cannot anticipate or control every application, we strongly recommend testing of this product under individual application conditions. In accordance with our policy of continuous improvement specification may vary.*

Permanento Edge-it B.V.  
Blik 10  
Industrial Estate Dombosch 1  
4941 SG Raamsdonksveer  
The Netherlands  
Tel: +31 162 58 94 00  
Fax: +31 162 52 02 14  
[r.hertzberger@permanento.com](mailto:r.hertzberger@permanento.com)  
[w.kraaij@permanento.com](mailto:w.kraaij@permanento.com)

